

# Yocto OS User Manual

## OS

### 1. OS Version

- a) Name: Yocto OS
- b) Kernel Version: Poky(4.0.9)

### 2. OS Login

- a) Username: root, no root password
- b) The system automatically logs in when it is switched on

### 3. Note

The system is equipped with power-up protection, which requires pressing the Power button to switch on the system.

## Processor Set

The RK3588 integrates four high-performance Arm Cortex-A76 CPU cores and four low-power Cortex-A55 CPU cores, along with a built-in high-frequency Mali-G52 GPU and an NPU co-processor.

### 1. CPU Temperature

- a) Chip centre temperature soc-thermal

```
cat /sys/class/thermal/thermal_zone0/temp
```

- b) CPU big core A76\_0/1; CPU4 and CPU5 temp

```
cat /sys/class/thermal/thermal_zone1/temp
```

- c) CPU big core A76\_2/3; CPU6 and CPU7 temp

```
cat /sys/class/thermal/thermal_zone2/temp
```

- d) CPU little core A55\_0/1/2/3; CPU0、CPU1、CPU2、CPU3 temp

```
cat /sys/class/thermal/thermal_zone3/temp
```

- a) GPU temp

```
cat /sys/class/thermal/thermal_zone5/temp
```

- b) NPU temp

```
cat /sys/class/thermal/thermal_zone6/temp
```

## 2. CPU Point Description

| Point   | Description                         |
|---------|-------------------------------------|
| policy0 | to set and read CPU little core 0~3 |
| policy4 | to set and read CPU big core 4~5    |
| policy6 | to set and read CPU big core 6~7    |

## 3. CPU Working Mode

### a) CPU Mode Description

| Mode         | Description   |
|--------------|---|
| interactive  | Runs at maximum frequency, gradually decreases depending on CPU compliance, disadvantage of high power consumption                            |
| conservative | Gradual and smooth CPU frequency adjustment, dynamic adjustment at upper and lower frequency limits   |
| ondemand     | The CPU switches to the highest frequency when it is performing calculations and drops to the lowest frequency at the end of the calculation. |
| userspace    | Provide API for users to set CPU frequency independently.   |
| powersave    | CPU fixed at lowest frequency   |
| performance  | Fixed operation at maximum frequency  |
| schedutil    | The system automatically adjusts the frequency according to the load  |

### b) CPU Operational mode reading

```
cat /sys/devices/system/cpu/cpufreq/policy0/scaling_available_governors
cat /sys/devices/system/cpu/cpufreq/policy4/scaling_available_governors
cat /sys/devices/system/cpu/cpufreq/policy6/scaling_available_governors
```

### c) CPU Operation mode setting

```
echo "mode" > /sys/devices/system/cpu/cpufreq/policy0/scaling_governor
echo "mode" > /sys/devices/system/cpu/cpufreq/policy4/scaling_governor
echo "mode" > /sys/devices/system/cpu/cpufreq/policy6/scaling_governor
```

## 4. CPU Operating Frequency

The default CPU working mode is schedutil mode, which does not support frequency setting. To set the frequency, you need to set the CPU working mode to userspace mode first.

### a) Get the current CPU supported frequency

```
cat /sys/devices/system/cpu/cpufreq/policy0/scaling_available_frequencies
cat /sys/devices/system/cpu/cpufreq/policy4/scaling_available_frequencies
cat /sys/devices/system/cpu/cpufreq/policy6/scaling_available_frequencies
```

- b) Set the CPU operating mode to userspace mode

```
echo userspace > /sys/devices/system/cpu/cpufreq/policy0/scaling_governor
echo userspace > /sys/devices/system/cpu/cpufreq/policy4/scaling_governor
echo userspace > /sys/devices/system/cpu/cpufreq/policy6/scaling_governor
```

- c) Setting the CPU frequency

```
echo xxx > /sys/devices/system/cpu/cpufreq/policy0/scaling_setspeed
echo xxx > /sys/devices/system/cpu/cpufreq/policy4/scaling_setspeed
echo xxx > /sys/devices/system/cpu/cpufreq/policy6/scaling_setspeed
```

- d) Check if the setup is successful

```
cat /sys/devices/system/cpu/cpufreq/policy0/cpuinfo_cur_freq
cat /sys/devices/system/cpu/cpufreq/policy4/cpuinfo_cur_freq
cat /sys/devices/system/cpu/cpufreq/policy6/cpuinfo_cur_freq
```

## 5. GPU Operating frequency

- a) Get the frequency supported by the GPU

```
cat /sys/class/devfreq/fb000000.gpu/available_frequencies
```

- b) Set GPU working mode

```
echo userspace > /sys/class/devfreq/fb000000.gpu/governor
```

- c) Setting GPU frequency

```
echo xxx > /sys/class/devfreq/fb000000.gpu/userspace/set_freq
```

- d) Check if the setup is successful

```
cat /sys/class/devfreq/fb000000.gpu/cur_freq
```

## 6. NPU Operating Frequency

- a) Get the frequency supported by the NPU

```
cat /sys/class/devfreq/fdab0000.npu/available_frequencies
```

- b) Setting the NPU working mode

```
echo userspace > /sys/class/devfreq/fdab0000.npu/governor
```


- c) Setting NPU frequency

```
echo xxx > /sys/class/devfreq/fdab0000.npu/userspace/set_freq
```

- d) Check if the setup is successful

```
cat /sys/class/devfreq/fdab0000.npu/cur_freq
```

## Board Setup



### 1. LED Settings

- a) Power(Red) LED does not support modification, only System(White) LED supports customization.
- b) To query System LED settable status.

```
cat /sys/class/leds/white_led/trigger
```

- c) Set to "default-on" as an example.

```
echo default-on > /sys/class/leds/white_led/trigger
```

- d) Additional notes on the "timer" model

Timer mode generates two profiles for setting the length of time the LEDs are on and off.

- i. Take setting the LED to light up for 100ms as an example

```
echo 100 > /sys/class/leds/white_led/delay_on
```

- ii. Take setting the LED off for 900ms as an example

```
echo 900 > /sys/class/leds/white_led/delay_off
```

## 2. LAN Setting

### a) LAN ON

- i. Enable LAN

```
ifconfig eth0 up
```

- ii. Connect the Internet and assign IP automatically.

### b) WoL Function Setting

- i. Enable Wake-on-LAN function

```
echo 1 > /sys/class/wol/eth0_enable
```

- ii. Enable WoL wake-up function and reset system function

```
echo 3 > /sys/class/wol/eth0_enable
```

- iii. Disable WoL function

```
echo 0 > /sys/class/wol/eth0_enable
```

## 3. Button Functional Description

### a) Power on and off

- i. After powering up the product, press the Power button briefly to switch on the device.
- ii. Press and hold the Power button to turn off the power.

### b) Device reset

Short press Reset button, system reset directly reboot.

### c) Firmware burning mode.

Quickly press the Function button 3 times in a row, the device enters the Maskrom burning mode.

## 4. Wi-Fi & BT Setting

### a) Wi-Fi&BT and NAMTSO Link are multiplexed PCIe, default is off, enable method:

- i. edit "/boot/uEnv.txt".

```
wifi=off → wifi=on
```

- ii. Reboot device Wi-Fi.

### b) Scan Wi-Fi:

```
wpa_cli -i wlan0 scan  
wpa_cli -i wlan0 scan_results
```

c) Connect Wi-Fi Device:

```
wpa_cli -i wlan0 add_network  
[network_id]  
wpa_cli -i wlan0 set_network [network_id] ssid ""ssid"  
wpa_cli -i wlan0 set_network [network_id] psk ""password"  
wpa_cli -i wlan0 enable_network [network_id]
```

d) Check the Wi-Fi:

```
iw wlan0 link
```

e) Obtaining a Wi-Fi IP address:

```
udhcpc -i wlan0
```

f) Turn on the Bluetooth device:

```
rfkill unblock all  
hciconfig hci0 up
```

g) Use Bluetooth control function:

```
bluetoothctl
```

h) Initialize and scan Bluetooth:

```
[bluetooth]# agent on  
[bluetooth]# default-agent  
[bluetooth]# power on  
[bluetooth]# discoverable on  
[bluetooth]# pairable on  
[bluetooth]# scan on  
[device list]
```

i) Connect Bluetooth Device:

```
[bluetooth]# connect [device address]
```

## 5. FAN Setting

a) Get the current working mode of the fan.

```
fan.sh mode
```

b) Fan operating mode setting.

```
Disable → fan.sh off  
Enable → fan.sh on  
Auto Mode → fan.sh auto  
Manual Mode → fan.sh manual
```

C) Fan speed setting(Only Manual Mode)

- i. Maximum speed mode:

```
fan.sh highest
```

- ii. High-speed mode:

```
fan.sh high
```

- iii. Medium speed mode:

```
fan.sh mid
```

- iv. Low speed mode:

```
fan.sh low
```

- iii. Minimum speed mode:

```
fan.sh lowest
```

## Overlay

1. Introduction of Overlay

Overlay function means to quickly overwrite the DTB and modify the system tree settings through dtbo file without recompiling the system source code. The Overlay function makes it easy to quickly test the reusable functions.

2. Overlay Function

Currently the A10-3588 has two default Overlay functions. PWM as well as SPI respectively, which can be changed to normal GPIOs after startup with Overlay named:

```
PWM: pwm-gpio-overlay.dtbo
SPI: spi-gpio-overlay.dtbo
```

3. Overlay Usage

- a) Overlay Files Specific location.

```
/boot/dtb/rockchip/rk3588-namtso-a10-3588.dtb.overlays/
```

- b) View current configurable Overlay features.

```
ls /boot/dtb/rockchip/rk3588-namtso-a10-3588.dtb.overlays/
pwm-gpio-overlay.dtbo  spi-gpio-overlay.dtbo
```

- c) Overlay Function Profiles.

```
/boot/dtb/rockchip/rk3588-namtso-a10-3588.dtb.overlay.env
```

- e) Take "pwm-gpio-overlay.dtbo" for example, save the edits and reboot the system, reload the DTB to take effect, after enabling this pwm port as a normal gpio use:

```
edit → /boot/dtb/rockchip/rk3588-namtso-a10-3588.dtb.overlay.env
fdt_overlays=pwm-gpio-overlay
```

- f) Use "pwm-gpio-overlay.dtbo", save the edits and reboot the system, reload the DTB

to take effect, after disabling this port as pwm functionality.

```
edit → /boot/dtb/rockchip/rk3588-namtso-a10-3588.dtb.overlay.env
fdt_overlays
```

g) For custom Overlay function, please refer to the SDK development documentation.

## Expansion Header

### 6. Expansion LED

a) Querying the Expansion LED setting status.

```
cat /sys/class/leds/ext_led/trigger
```

b) Set to "default-on", for example.

```
echo default-on > /sys/class/leds/ext_led/trigger
```

c) Supplementary note on the 'timer' model.

Timer mode generates two profiles for setting the length of time the LEDs are on and off.

iii. Take setting the LED to light up for 100ms as an example.

```
echo 100 > /sys/class/leds/ext_led/delay_on
```

iv. Take setting the LED off for 900ms as an example.

```
echo 900 > /sys/class/leds/ext_led/_led/delay_off
```

### 7. CAN

a) Open CAN:

```
ip link set can0 up
```

b) Close CAN:

```
ip link set can0 down
```

c) View CAN configuration information:

```
ifconfig -a | grep can
```

d) Set the baud rate:

```
ip link set can0 type can bitrate 250000
```

e) Receive CAN messages:

```
candump can0
```

f) Send messages:

```
cansend can0 123#1122334455667788
```



## 8. I2C

If `"/dev/i2c-2"` and `"/dev/i2c-4"` exist, you can use `i2c-tools` to manipulate this I2C interface.

- 1) List all available i2c buses:

```
i2cdetect -l
```

- 2) Retrieve devices on I2C4:

```
i2cdetect -y -r 4
```

- 3) Read the device connected to the I2C4:

```
i2cget -f -y 4 0x1d 0x0d
```

Its device address is `"0x1d"` and its register address is `"0x0d"`.

- 4) Set the device connected to the I2C4:

```
i2csset -f -y 4 0x1d 0x0d 0x02
```

Its device address is `"0x1d"` and register address is `"0x0d"`, modify it to `"0x02"`.

## 9. SPI

Just use `"ls /dev/spidev3.0"` to confirm that the spi bus is turned on.

## 10. UART

1. Device Point.

The left serial port is UART0, the right serial port is UART1.

```
/dev/ttyWCH0  
/dev/ttyWCH1
```

2. Baud rate setting.

Take UART0 as an example:

```
stty -F /dev/ttyWCH0 ispeed 115200 ospeed 115200 cs8  
stty -F /dev/ttyWCH0 speed 115200 cs8 -parenb -cstopb -echo
```

3. Send Data

```
echo "aaa" > /dev/ttyWCH0
```

4. Read Data

```
cat /dev/ttyWCH0
```

## 11. Power KEY

Same function as Power Button for external expansion of power buttons.

## Encoding and Decoding

1. Encoding

- a) Check the supported encoding formats:

```
gst-inspect-1.0 | grep mpp
rockchipmpp: mpph264enc: Rockchip Mpp H264 Encoder
rockchipmpp: mpph265enc: Rockchip Mpp H265 Encoder
rockchipmpp: mppjpegdec: Rockchip's MPP JPEG image decoder
rockchipmpp: mppjpegenc: Rockchip Mpp JPEG Encoder
rockchipmpp: mppvideodec: Rockchip's MPP video decoder
rockchipmpp: mppvp8enc: Rockchip Mpp VP8 Encoder
typefindfunctions: audio/x-musepack: mpc, mpp, mp+
```

- b) Encoding Mode NV12 to H.264:

```
gst-launch-1.0 -v filesrc location=./test.yuv ! videoparse width=1920 height=1080
format=nv12 ! mpph264enc ! h264parse ! queue ! filesink location=./test.h264
```

- c) Encoding USB camera:

```
gst-launch-1.0 v4l2src device=/dev/video80 io-mode=mmap num-buffers=300 !
image/jpeg, width=1920, height=1080, framerate=30/1 ! mppjpegdec !
mpph264enc ! filesink location=./test.h264
```

## 2. Decoding

- a) Check supported decoding formats:

```
gst-inspect-1.0 | grep mpp
rockchipmpp: mpph264enc: Rockchip Mpp H264 Encoder
rockchipmpp: mpph265enc: Rockchip Mpp H265 Encoder
rockchipmpp: mppjpegdec: Rockchip's MPP JPEG image decoder
rockchipmpp: mppjpegenc: Rockchip Mpp JPEG Encoder
rockchipmpp: mppvideodec: Rockchip's MPP video decoder
rockchipmpp: mppvp8enc: Rockchip Mpp VP8 Encoder
rockchipmpp: mppvp8alphadecodebin: VP8/VP9 Alpha Decoder
typefindfunctions: audio/x-musepack: mpc, mpp, mp+
```

- b) Decode MP4 files as an example:


```
gst-launch-1.0 filesrc location=./test.mp4 ! qtdemux name=d d.video_0 ! h264parse !
mppvideodec ! video/x-raw,format=NV12 ! filesink location=test.yuv
```

- c) Decode H.264 files:

```
gst-launch-1.0 filesrc location=./test.h264 ! h264parse ! mppvideodec ! video/x-
raw,format=NV12 ! filesink location=test.yuv
```

## Accessories

### 1. Expansion Board A9A10



- a) RS485  
Refer to the UART section of the motherboard for usage. The device node is:

```
/dev/ttyWCH2
```

- b) SATA  
i. Formatting.

```
mkfs.ext4 /dev/sdxv
```

- ii. Take the example of mounting to the mnt directory.

```
mount /dev/sdxv /mnt
```

c) 2.5 Gigabits LAN

- i. LAN1 Point is eth1, LAN2 Point is eth2.
- ii. Refer to the motherboard LAN section for usage.

d) RS232

Refer to the UART section of the motherboard for usage. The device node is:

```
/dev/ttyWCH3
```

e) M.2 Slot

- i. Formatting:

```
mkfs.ext4 /dev/nvmexny
```

- ii. Take the example of mounting to the mnt directory.

```
mount /dev/nvmexny /mnt
```